


Technical Datasheet

Chemical gas systems - FSL 1230™ / FSL 5112™



Actuation Options



* Note: Integral Solenoid cannot be fitted after the container is filled.

Life of Actuators

The life of all actuators is indefinite.

Recommended maintenance:

- Visually check for corrosion and damage every 6 months
- Replace Integral Solenoid core every 10 years.